



$$\left. \begin{array}{l} \text{ } \end{array} \right\} \underbrace{[E_1(u)]}_{\text{outer}} \wedge [+1] = E_1(u)$$

induced  
orientation  
for  $\partial\Sigma_+$

$$\left. \begin{array}{l} \text{ } \end{array} \right\} \underbrace{[-E_1(u)]}_{\text{outer}} \wedge [-1] = E_1(u)$$

induced  
orientation  
for  $\partial\Sigma_+$